











TL2M

Spare Parts List - Lista części zamiennych - Reservdelista -
ErsatzteillisteListe de pieces detachées - Lista de recambios



No.	Qty	Item number	Description	Part type
1	1	76375130	TL2M/TRS2 Drive shaft 6"	Spare part
2	1	76375119	TL2M/TRS2 Drive shaft 9"	Spare part
3	1	76375129	TL2M/TRS2 Drive shaft 12"	Spare part
4	1	76375276	TL2M/TRS2 Drive shaft 18"	Spare part
5	1	76375158	TL2M/TRS2 Drive shaft 24"	Spare part
6	1	76374767	TL2M Chain Wheel Dia. 35, 2 Pcs	Spare part
7	1	76375278	TL2M Casted rear end (2pcs)	Wear part
8	1	76375279	TL2M Casted Bends 60 Degree (2 Pcs)	Wear part
9	1	76375280	TL2M Gearmotor 0,37 kW ; 4,3 rpm; Shaft 35 mm	Spare part
10	1	76375281	TL2M Gearmotor 0,75 kW ; 11,1 rpm; Shaft 35 mm	Spare part
19	1	76376351	TL2M Key(For Chain Wheel) Dia. 35	Spare part
20	1	76376353	TL2M Key(For Drive Shaft) Dia. 35	Spare part
44	1	76376355	TL2M Flange bearing FYTB	Spare part
46	1	73002189	TL2M Passive Shaft; External Bearing; 6"	Spare part
47	1	73002190	TL2M Passive Shaft; External Bearing; 9"	Spare part
48	1	73002191	TL2M Passive Shaft; External Bearing; 12"	Spare part
49	1	73002192	TL2M Passive Shaft; External Bearing; 18"	Spare part
50	1	73002193	TL2M Passive Shaft; External Bearing; 24"	Spare part
51	1	73002194	TL2M Passive Shaft; External Bearing; 30"	Spare part
52	1	73002195	TL2M Passive Shaft; External Bearing; 36"	Spare part
53	1	73002196	TL2M Passive Shaft; External Bearing; 42"	Spare part
54	1	73002197	TL2M Passive Shaft; External Bearing; 48"	Spare part
55	1	73002198	TL2M Passive Shaft; External Bearing; 60"	Spare part



No.	Qty	Item number	Description	Part type
11	1	76374759	TL2M Rubber Scraper 9"	Wear part
12	1	76374760	TL2M Rubber Scraper 12"	Wear part
13	1	76374761	TL2M Rubber Scraper 18"	Wear part
14	1	76374762	TL2M Rubber Scraper 24"	Wear part
15	1	76375170	TL2M Flights 9"	Wear part
16	1	76375171	TL2M Flights 12"	Wear part
17	1	76375172	TL2M Flights 18"	Wear part
18	1	76375173	TL2M Flights 24"	Wear part
21	1	76376282	TL2M Belt shaft 6"	Spare part
22	1	76376283	TL2M Belt shaft 9"	Spare part
23	1	76376284	TL2M Belt shaft 12"	Spare part
24	1	76376291	TL2M Belt Shaft 18"	Spare part
25	1	76376285	TL2M Belt Shaft 24"	Spare part
26	1	76376286	TL2M Belt Shaft 30"	Spare part
27	1	76376287	TL2M Belt Shaft 36"	Spare part
28	1	76376288	TL2M Belt Shaft 42"	Spare part
29	1	76375133	TL2M Belt Shaft 60"	Spare part
30	1	73000230	TL2M Plate 6"	Wear part
31	1	76376345	TL2M Plate 9"	Wear part
32	1	76376346	TL2M Plate 12"	Wear part
33	1	76375283	TL2M Plate 18"	Wear part
34	1	76376347	TL2M Plate 24"	Wear part
35	1	76375132	TL2M Plate 60"	Wear part
36	1	73001113	TL2M Plate Carbonitrided 9"	Wear part
37	1	76376349	TL2M Side wing right	Wear part
38	1	76376348	TL2M Side wing left	Wear part
39	1	73001114	TL2M Side wing Carbonitrided; left	Wear part
40	1	73001115	TL2M Side wing Carbonitrided; right	Wear part
41	1	76376593	TL2M Screw M6x12 with washer	Spare part
42	1	76376350	TL2M Outer link TL2M	Spare part
43	1	76376352	TL2M Roller	Spare part
56	1	73000142	TL2M Rubber Scraper 6"; Low Profile	Wear part
57	1	73000143	TL2M Rubber Scraper 9"; Low Profile	Wear part
58	1	73000144	TL2M Rubber Scraper 12"; Low Profile	Wear part
59	1	73000145	TL2M Rubber Scraper 18"; Low Profile	Wear part
60	1	73000146	TL2M Rubber Scraper 24"; Low Profile	Wear part
61	1	73000147	TL2M Rubber Scraper 30"; Low Profile	Wear part
62	1	73000148	TL2M Rubber Scraper 36"; Low Profile	Wear part
63	1	73000149	TL2M Rubber Scraper 42"; Low Profile	Wear part
64	1	73000150	TL2M Rubber Scraper 48"; Low Profile	Wear part
65	1	73000151	TL2M Rubber Scraper 60"; Low Profile	Wear part